

Requirements to connect the ESI phone system for remote programming;

An available port on the data switch

An available local IP address that we can assign to phone system

(example; 192.168.1.25)

The subnet address

The default gateway

Very important!

Port forward 59002 (TCP) to the local IP address assigned to the phone system

(example; Port forward 59002 to 192.168.1.25)

The public static IP address if available;